

Turismos y vehículos comerciales ligeros



REF.	Ah	ARRANQUE EN FRIO		DIMENSIONES			ESQUEMA	BORNES	FIJACIÓN	RESPIRADERO
		DIN	SAE	LARGO	ANCHO	ALTO				
054	33	155	260	196	127	220	0	T1/T3	N	
055	33	155	260	187	127	220	1	T1/T3	N	
056	40	180	300	187	127	220	0	T1/T3	B3	
202	35	170	300	175	175	190	0	T1	B3	
048	45	210	350	220	135	225	0	T1	B1	
049	45	210	350	220	135	225	1	T1	B1	
053	45	230	380	238	129	227	0	T1	N	
063	45	230	380	207	175	175	0	T1	B3	●
077	45	230	380	207	175	175	1	T1	B3	
065	59	305	510	243	175	175	0	T1	B3	●
078	59	300	495	243	175	175	1	T1	B3	●
005	60	270	450	230	175	225	0	T1	N	●
027	60	330	540	243	175	190	0	T1	B3	●
100	68	390	650	278	175	175	0	T1	B3	●
069	72	355	590	261	175	220	1	T1	B5	●
072	72	355	590	265	175	205	1	T1	N	●
086	75	390	650	278	175	190	1	T1	B3	●
096	75	390	650	278	175	190	0	T1	B3	●
110	75	410	680	317	175	175	0	T1	B3	●
334	90	420	700	303	174	222	1	T1	B1	●
335	90	420	700	303	174	222	0	T1	B1	●
017	95	510	850	354	175	190	0	T1	B3	●
020	110	505	900	392	175	190	0	T1	B3	●

Llame al Centro de Atención al Cliente 902 360 113 y le informaremos de su distribuidor más cercano.